



## 5. Wiring Diagram

### 5-1. Wiring Diagram



5-2. Cables

| USE   |     | LVDS CABLE                                                                        | FUNCTION ASSY                                                                      |
|-------|-----|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|       |     | ASSY CABLE P-FFC CABLE                                                            | ASSY K/D-BOARD P                                                                   |
| Code  | 32" | BN96-35954E                                                                       | BN98-06044A                                                                        |
| Photo |     |  |  |



NOTE

The code number of cable can be changed, see "Exploded Views and Parts List".