

SAMSUNG

LED TV

Chassis : U88A

Model : U*32F4000A*

UN**F5000A*

UA**F5000A*

UN32F4200AG

UN**F5200AG

SERVICE Manual

LED TV



UN**F5000A*

Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

Contents

1. Precautions	1-1
1-1. Safety Precautions	1-1
1-2. Servicing Precautions	1-3
1-3. Static Electricity Precautions	1-4
1-4. Installation Precautions	1-5
2. Product Specifications	2-1
2-1. Product Information	2-1
2-2. Accessories	2-11
3. Disassembly and Reassembly	3-1
3-1. Disassembly and Reassembly	3-1
3-2. Assy Board P-Jog Switch & Ir	3-5
3-3. Disassembly(PTC).....	3-7
4. Troubleshooting	4-1
4-1. Troubleshooting	4-1
4-2. How to Check Fault Symptom	4-5
4-3. Factory Mode Adjustments	4-7
4-4. White Balance	4-22
4-5. White Ratio (Balance) Adjustment.....	4-25
4-6. Detail Specifications	4-27
4-7. Software Upgrade.....	4-46
4-8. Dimension.....	4-48
5. Wiring Diagram	5-1
5-1. Wiring Diagram.....	5-1
5-2. Connector	5-3
5-3. Connector Functions	5-6
5-4. Cables	5-7



**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.**

**© 2013 Samsung Electronics Co.,Ltd.
All rights reserved.
Printed in Korea**