



LED TV

Chassis : U8KB

Model : UN40H4200AG
UN48H4200AG

SERVICE Manual

LED TV



UN**H4200AG

Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

Contents

1. Precautions	1-1
1-1. Safety Precautions	1-1
1-1-1. Warnings.....	1-1
1-1-2. Servicing the LED TV	1-1
1-1-3. Fire and Shock Hazard	1-1
1-1-4. Product Safety Notices	1-2
1-2. Servicing Precautions.....	1-3
1-2-1. General Servicing Precautions	1-3
1-3. Static Electricity Precautions	1-4
1-4. Installation Precautions	1-5
2. Product Specifications.....	2-1
2-1. Product information	2-1
2-2. Product specification	2-2
2-2-1. Detailed Specifications	2-2
2-2-2. Specifications	2-7
2-3. Accessories	2-8
3. Disassembly and Reassembly	3-1
3-1. Disassembly and Reassembly	3-1
3-2. Disassembly(PTC).....	3-4
4. Troubleshooting	4-1
4-1. Troubleshooting.....	4-1
4-2. How to Check Fault Symptom	4-3
4-3. Factory Mode Adjustments	4-5
4-3-1. Detail Factory Option	4-5
4-3-2. Entering Factory Mode	4-6
4-3-3. Factory Data	4-7
4-4. White Balance	4-22
4-4-1. Calibration	4-22
4-4-2. Service Adjustment.....	4-22
4-4-3. Adjustment.....	4-24
4-5. White Ratio (Balance) Adjustment.....	4-25
4-6. Software Upgrade.....	4-27
4-6-1. How to Check the Software Version	4-27
4-6-2. How to Upgrade Software and Micom	4-29
4-7. Rear Cover Dimension	4-31
5. Wiring Diagram	5-1
5-1. Wiring Diagram.....	5-1
5-2. Connector	5-2
5-3. Connector Functions	5-4



**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.**

**© 2014 Samsung Electronics Co.,Ltd.
All rights reserved.
Printed in Korea**