

(Only those parts listed are available as spares)


[illegible]

EPSON

STYLUS C20SX


(Only those parts listed are available as spares)

Page 2



EPSON STYLUS C20UX,C20SX,C40UX,C40SX No.1

Rev.01 10317



EPSON STYLUS C20UX, C20SX, C40UX, C40SX No.2


Rev.01 10317

EPSON

STYLUS C20SX


(Only those parts listed are available as spares)

Page 4



EPSON STYLUS C20UX, C20SX, C40UX, C40SX No.3

Rev.01 10317



EPSON STYLUS C20UX,C40UX

No.4


Rev.01 10317

EPSON

STYLUS C20SX

(Only those parts listed are available as spares)

Page 6



EPSON STYLUS C20UX,C20SX,C40UX,C40SX No.5

Rev.01 10317