

EPSON
ACULASER C8500
CCS8500 ("Colour Copy Station 8500")
C813501 (Optional 1000-sheet Paper Cassette)
C813511 (Optional 500-sheet Paper cassette)
C813531 (Optional Duplex Unit)

Page 1

REF	PART NO	DESCRIPTION	SPEC	QTY
01-1-01	1059955	FRONT COVER ASSY		1
01-1-04	1042089	HINGE PLATE		2
01-1-05	1042090	FRONT LOWER COVER		1
01-1-06	1056816	FRONT MID COVER		1
01-1-10	1059957	L/H INNER COVER ASSY		1
01-1-12	1042092	ROTARY LATCH LEVER		1
01-1-13	1042093	ROTARY LATCH SPRING		1
01-1-14	1056818	IBT INNER COVER ASSY		1
01-1-15	1059958	R/H INNER COVER ASSY		1
01-1-21	1056820	TOP COVER		1
01-1-22	1056821	STOPPER COVER		1
01-1-31	1056822	REAR COVER		1
01-1-32	1042097	FILTER ASSY		1
01-1-35	1056823	REAR UPPER COVER		1
01-1-40	1056825	LEFT LOWER COVER		1
01-1-41	1056829	LEFT UPPER COVER		1
01-1-50	1056833	RIGHT LOWER COVER		1
01-1-51	1056836	RIGHT COVER ASSY		1
01-1-60	2034015	PANEL		1
01-1-70	1054755	LOGO PLATE,ASSY		1
02-1-01	1059959	UNIVERSAL TRAY		1
02-1-03	1042101	PLATE LINK SPRING		1
02-1-04	1042102	PLATE LINK		1
02-1-05	1042103	BOTTOM PLATE ASSY		1
02-1-06	1042104	TRAY N/F SPRING		2
02-1-08	1042105	FRONT GUIDE		1
02-1-09	1042106	FRONT SNUBBER		1
02-1-10	1042107	SNUBBER STOPPER		1
02-1-11	1059960	REAR GUIDE ASSY		1
02-1-15	1042109	REAR GUIDE SPRING		2
02-1-16	1057875	END GUIDE		1
02-1-17	1042111	TRAY SIZE ACTUATOR		1
02-1-18	1054098	CAM PLATE		1
02-1-19	1054100	SPRING		1
03-1-01	1056864	TURN COVER STOPPER		1
03-1-05	1042128	SIZE SWITCH ASSY		1
03-1-07	2028570	TRAY SENSOR ASSY		1
03-1-11	1056865	TURN CHUTE UP ASSY		1
03-1-17	1056866	TURN CHUTE COVER		1
03-1-18	2029259	LOW PAPER SENSOR		1
03-1-21	1056867	TURN IN CHUTE		1
03-1-22	1056868	TURN CHUTE ASSY		1
03-1-23	1056869	TURN ROLL ASSY		1
03-1-25	1056870	TURN GEAR S		1
03-1-26	1056871	TURN GEAR L		1
03-1-27	1056872	TURN GEAR M		1
03-1-28	1056873	TURN GEAR D		2
03-1-29	1042112	FEED ROLL ASSY		1
03-1-31	1042113	FEED ROLL		2
03-1-35	2028229	FEED SOLENOID		1
03-1-36	1042115	FEED GEAR		1
03-1-37	1042116	FEED SPRING		1
03-1-38	1042117	FEED IDLER GEAR		1
03-1-40	1042127	TRAY STOPPER		1
03-1-41	1056874	TURN UPPER CHUTE		1
03-1-42	1056875	TURN CLUTCH		1

EPSON

ACULASER C8500

Page 2

REF	PART NO	DESCRIPTION	SPEC	QTY
03-1-46	2035740	TURN CHUTE HARNESS		1
03-1-47	1056876	TURN GEAR COVER		1
03-1-48	2028259	EXIT CHUTE SWITCH		1
04-1-03	2028259	EXIT CHUTE SWITCH		1
04-1-06	2037296	MSI ASSY		1
04-1-40	2035747	MAIN P/H FRAME ASSY		1
04-1-50	1059961	MSI TRAY ASSY		1
04-2-04	1056878	P/B PAD		1
04-2-08	2035742	MSI HARNESS ASSY		1
04-2-09	1056879	GEAR 28		1
04-2-10	2035743	BOTTOM PLATE SENSOR		1
04-2-20	1056880	LIFT UP FRAME ASSY		1
04-2-26	2035744	LIFT MOTOR ASSY		1
04-3-05	2021773	E.R.M. SENSOR		1
04-3-06	2028232	SENSOR		1
04-3-07	1056881	MSI N/P ACTUATOR		1
04-3-20	2035745	MSI FEED FRAME ASSY		1
04-3-23	2035743	BOTTOM PLATE SENSOR		1
04-3-28	1056883	ROLL		1
04-3-29	1056884	FEED ROLL		1
04-3-39	1056886	ETD SPRING		1
04-3-41	1056888	PICK UP CLUTCH		1
04-3-45	1056889	RETARD ROLL		1
04-4-03	1056890	P/REG. ROLL ASSY		1
04-4-04	2035748	PRE REG. CLUTCH ASSY		1
04-4-05	2035748	PRE REG. CLUTCH ASSY		1
04-4-16	2035749	REG. HARNESS ASSY		1
04-4-20	1042164	P/H FRONT RAIL-L		1
04-4-21	1042166	P/H REAR RAIL-L		1
04-4-24	2028232	SENSOR		1
04-4-25	2028232	SENSOR		1
REF 05-	N/A	NOT USED		
06-1-01	2035750	ROS ASSY		1
06-1-20	2035751	ADC SENSOR ASSY		1
06-1-30	2035752	ERASE LAMP ASSY		1
06-1-42	2028242	WASTE TONER SENSOR		1
06-1-43	2028243	TONER BOX SENSOR		1
06-1-44	2028244	TONER BOX HARNESS		1
06-1-50	1042187	BCR CONNECTOR ASSY		1
06-1-60	2035753	RECEPTICLE ASSY		1
06-1-70	2028245	CRUM CONNECTOR ASSY		1
07-1-10	1059966	DEVELOPER ASSY YELLOW		1
07-1-20	1059967	DEVELOPER ASSY MAGENTA		1
07-1-30	1059968	DEVELOPER ASSY CYAN		1
07-1-40	1059969	DEVELOPER ASSY BLACK		1
07-2-02	1063862	ROTARY FRAME ASSY		
07-2-05	1042192	ROTARY LATCH ASSY		1
07-2-11	1056892	DEV.CONTACT PLATE ASSY		1
07-2-22	1042195	ROTARY SENSOR		1
07-2-32	2028248	USED CART.SENSOR		1
08-1-01	2035759	2ND BTR CAM ASSY		1
08-1-02	1056893	BTR REAR BRACKET ASSY		1
08-1-06	1056894	AUGER HIGH ASSY		1
08-1-11	1056895	IBT REAR BRACKET ASSY		1
08-1-20	2035760	TRANSFER HIGH ASSY		1
08-1-21	1056896	TENSION LEVER		1
08-1-22	2035761	2ND BTR ASSY		1
08-1-23	2035762	BELT CLEANER ASSY		1
08-2-02	1056901	IBT BELT ASSY		1
08-2-33	2035763	TRO SENSOR		1
08-3-02	2035764	BTR CAM CLUTCH		1
08-3-03	2035765	CAM ASSY-M		1
08-3-04	2035743	BOTTOM PLATE SENSOR		1
09-1-02	2037300	MAIN FUSER ASSY+		1
09-1-03	2037302	FUSER TRAY ASSY		1
09-2-03	2021773	E.R.M. SENSOR		1
09-2-04	2021773	E.R.M. SENSOR		1
09-2-06	2035768	TEMP.SENSOR ASSY		1

EPSON

ACULASER C8500

Page 3

REF	PART NO	DESCRIPTION	SPEC	QTY
09-2-10	1056902	PRESSURE ROLL		1
09-2-13	1056903	LOWER GUIDE ASSY		1
09-2-25	1056904	HEAT ROLL		1
09-2-26	1042206	BEARING		2
09-2-28	1056905	H/R GEAR		1
09-2-29	1056906	H/R RING		2
09-2-30	1059970	FUSER UPPER ASSY+		1
09-2-31	1056907	STS SEAL		1
09-2-32	1049487	SEAL Q/L		2
09-2-37	2037304	H/R (230)		1
09-2-38	2037306	P/R (230)		1
09-2-43	1056908	FUSER NIP HANDLE		1
09-3-04	1056909	FUSER TRAY LEVER		1
09-3-05	1042214	FUSER TRAY CAP-B		1
09-3-06	1056910	FUSER FRONT RAIL		1
09-3-07	1056911	FUSER REAR RAIL		1
09-3-14	1056912	EXIT-1 ROLL ASSY		1
09-3-17	1042217	EXCHANGE CHUTE		1
09-3-22	2028253	EXCHANGE SOLENOID		1
09-3-29	2035772	FUSER HARNESS ASSY		1
09-3-30	1063128	GEARS PAIR FUSER TRAY	MODIFIED GEARS WHITE	
09-4-03	2028255	FUSER TRAY CAP-A		1
09-4-04	2021773	E.R.M. SENSOR		1
09-4-07	1042226	FUSER IN ACTUATOR		1
09-4-08	1042227	FUSER IN SPRING		1
09-4-10	2028257	FUSER CHUTE FAN		1
09-4-14	1056913	INPUT BRACKET ASSY		1
09-4-22	1056914	CLEANER CAM GEAR		1
09-4-24	2035773	CLEANER CAM SOLENOID		1
09-4-25	1042233	CLEANER CAM ASSY		1
10-1-01	2035774	EXIT LOWER ASSY		1
10-1-02	1056915	EXIT ASSY		1
10-1-10	1042239	EXIT TRAY ASSY		1
10-2-04	1056916	FUSER PINCH ASSY		2
10-2-05	1042240	EXIT-2 ROLL ASSY		1
10-2-06	1042241	EXIT-3 ROLL ASSY		1
10-2-12	2028258	TOP EXIT SENSOR		1
10-2-13	2028259	EXIT CHUTE SWITCH		1
10-2-14	2035777	EXIT HARNESS		1
10-2-15	2035778	FUSER FAN-1		1
10-2-16	2035779	EXIT CHUTE FAN		1
11-1-01	1056917	P/H DRIVE ASSY		1
11-1-02	1056918	FUSER DRIVE ASSY		1
11-1-04	2035780	FUSER MOTOR ASSY		1
11-1-05	2035781	P/H MOTOR ASSY		1
11-1-06	2035782	DRIVE MOTOR PWB		1
11-1-10	2035783	PROCESS DRIVE ASSY		1
11-1-20	2035784	ROTARY MOTOR ASSY		1
11-1-21	2035785	ROTARY MOTOR DRIVE PWB		1
11-1-22	2035786	DISPENSE CLUTCH ASSY		1
11-1-23	2035787	DEVE.CLUTCH ASSY		1
12-1-28	1042245	FRAME FOOT		4
12-1-29	1056919	SHEET CLAMP		2
13-1-01	2035788	LOW VOLTAGE POWER SUPPLY		1
13-1-02	2035789	HIGH VOLTAGE POWER SUPPLY		1
13-1-03	2028267	TOP COVER SWITCH		1
13-1-05	2035790	DEVE.FAN		1
13-1-14	2035791	BCR WIRE		1
13-1-15	2035792	DEV.WIRE		1
13-1-16	2035793	MAIN HARNESS ASSY		1
13-1-17	2035794	FUSER CONNECTOR		1
13-1-20	2029164	POWER CABLE		1
13-1-20	2029165	POWER CABLE		1
13-1-20	2029253	POWER CABLE		1
13-1-20	2036256	POWER CORD		1
13-1-20	2037206	POWER CABLE		1
13-2-01	2035795	MCU PWB		1
13-2-02	2035796	COMMUNICATION PWB		1

EPSON

ACULASER C8500

Page 4

REF	PART NO	DESCRIPTION	SPEC	QTY
13-2-03	2028274	FRONT COVER SWITCH RIGHT		1
13-2-04	2035797	FRONT COVER SWITCH LEFT		1
13-2-05	2035798	ENVIRONMENT SENSOR		1
13-2-20	2035799	P/H HARNESS ASSY		1
13-2-21	2035800	ROS HARNESS		1
14-1-01	1056920	CONT.CHASSIS ASSY		1
14-1-02	2028280	CONTROLLER FAN		1
14-1-20	2035647	WIRE HARNESS		1
14-1-26	1012855	GROUNDING SPRING,TYPE-B		1
14-1-27	1012848	GUIDE RAIL		1
14.1.200	2035663	BOARD ASSY., MAIN		1
		COLOUR COPY STATION (CCS 8500)		
100	1060926	UPPER CASE SET;AE		1
101	1059469	OP COVER		1
102	1059468	ACCESSORY SET		1
103	1061672	LOWER CASE		
200	2038424	MAIN BOARD;AE		1
201	2037010	SWITCH BOARD ,A		1
202	2037011	SWITCH BOARD,B		1
203	2037012	SWITCH BOARD,C		1
205	2034682	BOARD ASSY.,INTERFACE		1
206	2037270	BOARD ASSY.,MEMORY		1
207	2033005	RAN BOARD EPM-128M		1
208	2037009	SENSOR ASSY		1
209	1053939	INSTALLATION METAL FITTINGS,PANEL		1
204	2034633	BOARD ASSY.,INTERFACE		1
400	2034638	WIRE HARNESS		1
401	2034639	WIRE HARNESS		1
END				
		1000-SHEET PAPER CASSETTE (C813501)		
1.1.03	1061258	500 TRAY ASSY		
2.1.01	1057615	FEEDER FRONT COVER		
2.1.10	1057616	FEEDER LEFT COVER		
2.1.20	1057617	FEEDER RIGHT COVER		
2.1.21	2028259	EXIT CHUTE SWITCH		
2.1.22	2035801	COVER SWITCH HARNESS		
2.1.30	1057618	FEEDER CHUTE ASSY		
2.1.40	1056927	DOUBLE CASTER-F		
3.1.01	2035802	FEEDER HIGH ASSY		
3.1.03	2035803	FEEDER MOTOR ASSY		
3.1.04	2035804	FEEDER DRIVE ASSY		
3.1.07	2030397	TRAY 3 PAPER SIZE SENSOR PWB		
3.1.09	2048507	FEEDER PWB		
3.1.13	2035807	FEEDER HARNESS		
3.1.22	1056931	SHEET CLAMP		
3.1.30	2021773	E.R.M. SENSOR		
3.2.11	1056969	RETARD ROLL ASSY		
3.2.21	2035812	UPPER FRAME ASSY		
3.2.25	1056973	NUDGER ROLL ASSY		
3.2.29	1056875	TURN CLUTCH		
3.2.32	1056974	NUDGER LEVER		
3.2.33	2035817	NUDGER SENSOR		
3.2.35	1056975	FEED ROLL ASSY		
3.2.36	2028232	SENSOR		
3.2.45	2035818	NO PAPER SENSOR		
3.2.50	1056976	TA ROLL ASSY		
3.2.51	2035821	NUD SOLENOID ASSY		
3.2.56	2035822	TURN CLUTCH ASSY		

EPSON

ACULASER C8500

Page 5

REF	PART NO	DESCRIPTION	SPEC	QTY
4.1.03	1057619	SIDE GUIDE LOCK KNOB		
4.1.09	1045191	END GUIDE SPRING		
4.1.10	1057620	LEVER ASSY		
4.1.21	1057621	END GUIDE		
4.1.24	1057622	FRONT TRAY COVER		
4.1.25	1042109	REAR GUIDE SPRING		
		500-SHEET PAPER CASSETTE		
		C813511		
REF	PART NO	DESCRIPTION	SPEC	
1.1.03	1061258	500 SHEET TRAY ASSY		1
2.1.01	1057615	FEEDER FRONT COVER		2
2.1.10	1057616	FEEDER LEFT COVER		1
2.1.20	1057617	FEEDER RIGHT COVER		1
2.1.21	2028259	EXIT CHUTE SWITCH		2
2.1.22	2035801	COVER SWITCH HARNESS		1
2.1.30	1057618	FEEDER CHUTE ASSY		1
2.1.40	1056927	DOUBLE CASTOR-F		4
3.1.01	2035802	FEEDER HIGH ASSY		1
3.1.03	2035803	FEEDER MOTOR ASSY		1
3.1.04	2035804	FEEDER DRIVE ASSY		1
3.1.07	2030397	TRAY 3 PAPER SIZE SNR PWB		2
3.1.09	2048507	FEEDER PWB		1
3.1.13	2035807	FEEDER HARNESS		1
3.1.22	1056931	SHEET CLAMP		2
3.1.30	2021773	E.R.M. SENSOR		1
3.2.11	1056969	RETARD ROLL ASSY		1
3.2.21	2035812	UPPER FRAME ASSY		1
3.2.25	1056973	ROLL ASSY		1
3.2.29	1056875	TURN CLUTCH		1
3.2.32	1056974	LEVER		1
3.2.33	2035817	SENSOR		1
3.2.35	1056975	FEED ROLLER ASSY		1
3.2.36	2028232	SENSOR		1
3.2.45	2035818	NO PAPER SENSOR		1
3.2.50	1056976	TA ROLL ASSY		1
3.2.51	2035821	NUD SOLENOID ASSY		1
3.2.56	2035822	TURN CLUTCH ASSY		1
4.1.03	1057619	SIDE GUIDE LOCK KNOB		1
4.1.09	1045191	END GUIDE SPRING		1
4.1.10	1057620	LEVER ASSY		1
4.1.21	1057621	END GUIDE		1
4.1.24	1057622	FRONT TRAY COVER		1
4.1.25	1042109	REAR GUIDE SPRING		1
		DUPLEX UNIT		
		(C813531)		
1.1.02	2041970	DUP TRANSPORT ASSY		1
1.1.03	2048547	ALIGNER ASSY		1
1.1.04	2048546	INVERTER ASSY		1
1.1.07	2035823	LWR INVERTER SOLENOID		1
1.1.08	1056980	LWR INVERTER SOLENOID SPRING		1
1.1.15	1057582	OPTION CAP A		1
2.1.03	1056981	GATE DUPLEX		1
2.1.06	2035824	DUP GATE SOLENOID		1
2.1.11	1056982	PINCH ROLL ASSY		4
2.1.16	1056983	EXIT ROLLER ASSY		1
3.1.03	1056984	IN ROLLER ASSY		1
3.1.04	1056985	OUT ROLLER ASSY		1
3.1.05	1056986	REGI ROLLER ASSY		1
3.1.06	1056987	IN CHUTE ASSY		1

EPSON

ACULASER C8500

Page 6


REF	PART NO	DESCRIPTION	SPEC	QTY
3.1.07	2035826	OUT CHUTE ASSY		1
3.1.09	2028232	SENSOR		1
3.1.10	2035827	REGI CHUTE ASSY		1
3.1.13	1056988	CHUTE SUPPORT		1
3.1.14	1057583	ALIGNER COVER-FR		1
3.1.15	1056990	R/H ASSY		1
3.1.22	2035829	ALIGNER DRIVE CLUTCH		1
3.1.34	1056919	SHEET CLAMP		4
3.1.43	2035830	ALIGNER HARNESS ASSY		1
3.1.45	1057584	REG. ROLLER ASSY-B10		2
4.1.03	1056991	PINCH ROLLER ASSY		3
4.1.04	2028259	EXIT CHUTE SWITCH		1
4.1.09	1063867	4 CHUTE ASSY		1
4.1.10	1056993	CHUTE 2		1
4.1.11	2035831	DUP CONTROLLER PWB		1
4.1.16	1056875	TURN CLUTCH		1
4.1.17	1056875	TURN CLUTCH		1
4.1.18	1056875	TURN CLUTCH		1
4.1.19	1056994	LINK PINCH		1
4.1.21	1056995	INVERTER 2 ROLLER ASSY		1
4.1.22	1056996	ROLLER ASSY PINCH		1
4.1.23	1056997	INVERTER ROLLER ASSY		1
4.1.26	2035834	INVERTER MOTOR		1
4.1.27	2035758	INVERTER CHUTE ASSY		1
4.1.29	1056998	PINCH ROLL ASSY		1
4.1.32	2028258	TOP EXIT SENSOR		1
4.1.34	1056999	TRI ROLL ASSY		1
4.1.39	1057000	COVER SUPPORT L/H		1
4.1.40	1057585	F COVER INVERTER		1
4.1.41	1057586	R COVER INVERTER		1
4.1.42	1057001	LINK SPRING PINCH		1
4.1.43	2035835	HARNESS ASSY DUP		1
4.1.44	2035836	DUP MAIN HARNESS ASSY		1
END				

EPSON

ACULASER C8500

Page 7

The parts to which no reference number is assigned will not be available as after-sale service parts.




AcuLaser C8500 (1.1) ^{TBK501FA}
10252 Rev.01

EPSON ACULASER C8500

Page 8

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK503FA

AcuLaser C8500 (2.1)


10252 Rev.01

EPSON

ACULASER C8500

Page 9

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK504FA

AcuLaser C8500 (3.1)


10252 Rev.01

EPSON

ACULASER C8500

Page 10

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK505FA

AcuLaser C8500 (4.1)


10252 Rev.01

EPSON

ACULASER C8500

Page 11

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (4.2)

10252 Rev.01


TBK508FA

EPSON

ACULASER C8500

Page 12

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (4.3)

10252 Rev.01


TBK507FA

EPSON

ACULASER C8500

Page 13

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK508FA

AcuLaser C8500 (4.4)


10252 Rev.01

EPSON

ACULASER C8500

Page 14

The parts to which no reference number is assigned will not be available as after-sale service parts.




AcuLaser C8500 (6.1)
10252 Rev.01

TBK510FA

C374-MECH-092

The parts to which no reference number is assigned will not be available as after-sale service parts.




EPSON

ACULASER C8500

Page 16

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK513FA


AcuLaser C8500 (8.1)
10252 Rev.01

EPSON

ACULASER C8500

Page 17

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (8.2)


10252 Rev.01

TBK514FA

EPSON ACULASER C8500

Page 18


The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK515FA

AcuLaser C8500 (8.3)
10252 Rev.01

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK517FA

AcuLaser C8500 (9.1)


10252 Rev.01

EPSON

ACULASER C8500

Page 20

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (9.2)

10252 Rev.01

TBK518FA


EPSON

ACULASER C8500

Page 21

C374-MECH-151

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (9.3)


10252 Rev.01

EPSON

ACULASER C8500

Page 22

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (9.4)

10252 Rev.01


TBK520FA

EPSON

ACULASER C8500

Page 23

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK521FA


AcuLaser C8500 (10.1)
10252 Rev.01

EPSON

ACULASER C8500

Page 24

The parts to which no reference number is assigned will not be available as after-sale service parts.




TBK522FA

AcuLaser C8500 (10.2)
10252 Rev.01

EPSON

ACULASER C8500

Page 25



AcuLaser C8500 (11.1)
10252 Rev.01


TBK523FA

EPSON

ACULASER C8500

Page 26

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (12.1)

10252 Rev.01


TBK524FA

EPSON

ACULASER C8500

Page 27

The parts to which no reference number is assigned will not be available as after-sale service parts.



AcuLaser C8500 (13.1)

10252 Rev.01


TBK525FA

EPSON

ACULASER C8500

Page 28


The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK526FA

AcuLaser C8500 (13.2)
10252 Rev.01

The parts to which no reference number is assigned will not be available as after-sale service parts.




TBK527EA

AcuLaser C8500 (14.1)


10252 Rev.01

EPSON ACULASER C8500

Page 30




CCS-8500 NO.1



CCS-8500 No.2

C813-OTHE-006


The parts to which no reference number is assigned will not be available as after-sale service parts.



C813501 1000 SHEET CAPACITY PAPER CASSETTE - FIG. 1.1


C813-OTHE-007

The parts to which no reference number is assigned will not be available as after-sale service parts.



C813501 1000 SHEET CAPACITY PAPER CASSETTE - FIG. 2.1

The parts to which no reference number is assigned will not be available as after-sale service parts.



C813501 1000 SHEET CAPACITY PAPER CASSETTE - FIG. 3.1


EPSON

ACULASER C8500

Page 34

The parts to which no reference number is assigned will not be available as after-sale service parts.


C813-OTHE-009



C813501 1000 SHEET CAPACITY PAPER CASSETTE - FIG. 3.2

C813-OTHE-010


The parts to which no reference number is assigned will not be available as after-sale service parts.



C813501 1000-SHEET PAPER CASSETTE FIG. 4.1

C813-OTHE-001


The parts to which no reference number is assigned will not be available as after-sale service parts.



C813511 500 SHEET PAPER CASSETTE UNIT - FIG.1.1

C813-OTHE-002

The parts to which no reference number is assigned will not be available as after-sale service parts.




TBF1502FA

C813511 500 SHEET PAPER CASSETTE UNIT - FIG.2.1

C813-OTHE-003

The parts to which no reference number is assigned will not be available as after-sale service parts.




TBF1503FA

C813511 500 SHEET PAPER CASSETTE UNIT - FIG.3.1

C813-OTHE-005

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBF1505FA


C813511 500 SHEET PAPER CASSETTE UNIT - FIG.4.1

EPSON

ACULASER C8500

Page 40

The parts to which no reference number is assigned will not be available as after-sale service parts.




TBK3501FA

DUPLEX UNIT (1.1)

10321 Rev.01

C813531

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK3502FA


DUPLEX UNIT (2.1) 10321 Rev.01

C813531

EPSON ACULASER C8500

Page 42

The parts to which no reference number is assigned will not be available as after-sale service parts.



FOR DUPLEX UNIT (3.1) 10321 Rev.01


TBK3503FA

EPSON

ACULASER C8500

Page 43

The parts to which no reference number is assigned will not be available as after-sale service parts.



TBK3504FA

FOR DUPLEX UNIT (4.1) 10321 Rev.01

C813531